



## Fact sheet – Lean Meat Yield Current and Future Technologies

**Date of issue: 27 January 2015**

Lean meat yield is one profit driver within lamb supply chains, driving on-farm efficiency, reducing wastage and new product development at processing.

*Lean meat yield percentage (LMY%) is the amount of lean meat that can be boned out from a carcass and is displayed as a percentage of carcass weight.*

Determining lamb LMY% is valuable for processors. While LMY% proved to be difficult to measure at chain speed, there are a number of methods that can predict LMY% with varying accuracy.

Identifying appropriate in-plant measurement technologies could increase value by up to \$10 per carcass, depending on the ease and degree of fabrication or retrofitting to existing processing plant.

### Current measurements to predict LMY%

In Australia, most carcasses are graded and traded on the basis of carcass weight and GR tissue depth.

*GR tissue depth is a single point measurement taken 110 mm from the spine over the 12th rib (the GR site), representing the total depth of tissue (muscle and fat) at this point.*

While grading carcasses on the basis of GR tissue depth is an industry standard, the way in which this is measured is not.

**Table 1** compares methods of predicting LMY%. The accuracy is determined by both the measurements and carcass weight. In most cases, technologies are trained or calibrated using bone-out data generated by professional butchers, however, in recent years the use of Computed Tomography (CT) scans for benchmarking and training has increased in Australia (Figure 1).\*



**Figure 1:** Lamb carcass CT scan

### Improving LMY% Prediction

Plants currently palpating GR fat score, could more accurately predict LMY% by using a GR Knife, AUS-MEAT Sheep Probe or VIAscan®.

**Table 1:** Current methods of LMY% determination

LMY Prediction Method	Accuracy to predict LMY% *	Most suited to and Benefits	Limitations
<b>HSCW</b>	HSCW 12%		
<b>HSCW plus Palpated Fat Score</b> (AUSmeat accredited operators)	Fat score + HSCW 20%	Measure on hot carcasses, end of chain	Higher operator error (especially at fast speed)
<b>HSCW plus GR Knife Fat Score</b> (measured fat scores)	GR Fat score + HSCW 30%	Slower chain speeds End of the chain	Fast chain speed
<b>HSCW plus GR Knife (mm)</b> (measured with ruler)	GR mm + HSCW 35%	Slower chain speeds End of the chain	Fast chain speed

**PROGRAM: FOOD SAFETY, PRODUCT INTEGRITY AND MEAT SCIENCE**



<b>HSCW plus AUSmeat Sheep</b> Probe Blade driven through GR tissue until it strikes the rib	Probe + HSCW 34.6%**	Measure on hot bodies Slower chain speeds End of the chain	Operator error and no longer commercially supported
<b>VIAscan®</b> HSCW, carcass dimensions and light reflectance measured	47%	Operates with modern kill chains, no human error	Ageing technology

\*Precision of new yield prediction technologies based on their ability to predict CT lean %.

**Measuring alternate tissue depths**

The Sheep CRC Information Nucleus Flock has measured tissue depths at key points within the carcass to determine their ability to predict LMY%, when used in conjunction with carcass weight (Table 2). These combinations do slightly increase the accuracy of prediction, although the task of measuring the additional points is only likely to provide additional value to plants routinely cutting and sorting carcasses.

**Table 2** Accuracy of measuring alternate tissue depths to predict LMY%

Accurately measured tissue depths	Accuracy to predict LMY% *
HSCW + GR (mm)	35
HSCW + EMD + C-fat	36
HSCW + EMA + C-fat	40
HSCW + GR (mm) + EMD + C-fat	47

\* Precision of yield prediction measurements based on their ability to predict CT lean %.

**HSCW:** hot standard carcass weight

**GR (mm):** GR tissue depth measured by ruler or GR knife

**EMD:** eye muscle depth

**CFAT:** fat depth measured at the C-site (over the 12th rib 5 cm from the spine)

**EMA:** eye muscle area

**FS:** fat score, corresponds to GR depths measured in 5 mm graduations

**Future methods of LMY% determination**

A number of new devices with potential for future use are being investigated through collaboration with commercial partners.

Point measures:

- Modification of the Carometec Fat-o-Meat'er: a probe type device to measure the GR site.
- High resolution camera imaging for determining fat depth and eye muscle area at the C-site of cut carcasses.
- An intramuscular fat probe based on electrical impedance detected via insertion into the muscle.

Image analysis:

- VIAscan® records and analyses carcass surface images to extract measurements to predict the lean meat yield of the carcass. Use of 2D X-ray to steer robotic cutting devices is increasing. Research into more accurate LMY% determination is being trialed with modifications to dual energy x-ray absorptiometry (DEXA) technology.

**Tested/failed methods of LMY% prediction**

A range of devices have also been assessed within the Sheep CRC, in many cases pursued on the basis of their capacity to capture tissue depths at key points within the carcass. At this stage none of these are considered accurate enough for use or capable on their own of determining LMY% prediction in lamb.

- Hennessy Grading Probe
- Pork Scan Ultrasound Probe
- Cut-based weighing yield prediction
- 2D X-ray scanning



### Summary

Plants currently palpating GR fat score, especially at high speeds, could more accurately predict LMY% by simply using a GR Knife to measure either fat score or GR depth (mm). For increased accuracy use an AUS-MEAT Sheep Probe or VIAscan®.

### Disclaimer

The information contained within this publication has been prepared by a third party commissioned by the Australian Meat Processor Corporation Ltd (AMPC). It does not necessarily reflect the opinion or position of AMPC. Care is taken to ensure the accuracy of the information contained in this publication. However, AMPC cannot accept responsibility for the accuracy or completeness of the information or opinions contained in this publication, nor does it endorse or adopt the information contained in this report.

No part of this work may be reproduced, copied, published, communicated or adapted in any form or by any means (electronic or otherwise) without the express written permission of Australian Meat Processor Corporation Ltd. All rights are expressly reserved. Requests for further authorisation should be directed to the Chief Executive Officer, AMPC, Suite 1, Level 5, 110 Walker Street Sydney NSW.